

RP1300 Flow Control Valve Installation

Remove existing fitting
and valve.
(may be 1 or 2 pieces)

Install RP1300 and tighten.

NOTE;
If the plunger and spring
(not included)
have been removed
replace as shown.

